


# Closed and Open Tray Impressions

## Closed-Tray (Indirect) Procedure




1. Seat Impression Posts onto implants and secure retaining screws with the 1.25mmD (0.050") Hex Tool.



2. For a closed-tray (indirect) impression, retaining screws are used that match the height of the Impression Post. Screws are included with the Impression Posts.



3. Block out holes on top of the screws with wax or other suitable material to prevent impression material from entering.



4. Record the impression. Place light body impression material around the Impression Posts and record a full-arch impression with standard body material.




5. Unscrew each Impression Post from the implant body using the 1.25mmD (0.050") Hex Tool and attach the appropriate Implant Body Analog with the same retaining screw.



6. Place the Impression Posts back into the impression material with the analogs attached. The impression is now ready to send to the laboratory for fabrication of a working cast.


## Open-Tray (Direct) Procedure




7. For an open-tray (direct) impression technique, use the Impression Posts with optional long retaining screws (sold separately). Attach the Impression Posts to the implants with the 1.25mmD (0.050") Hex Tool.



8. Use a custom tray and prepare holes that will line up with the Impression Posts when the impression is taken.




9. Place light body impression material around the Impression Posts and record a full-arch impression with standard body material. The screws will protrude through the tray.



10. With the tray still in place, unscrew and remove all the retaining screws. Then remove the tray, capturing the Impression Posts in the impression material.



11. After removing the impression tray, connect the Implant Body Analogs to the Impression Posts which are still in place in the impression material.



12. Screw Impression Posts and analogs together with the 1.25mmD (0.050") Hex Tool. Hold the analog in place to prevent rotation of the Impression Post. Send the impression to the laboratory for fabrication of a working cast.

**Note: This guide is for educational use only.**

Refer to the Zimmer Dental Division Prosthetics Instructions for Use (part #4894), and Instructions for Use (part #'s 4869 and 4718) for complete instructions for use.

